



HIGH
ANCHOR POINT

BELT




Pressure and balance zone of the harness anchor point: middle-abdomen.

Intended for: Users who prioritize vertical progression in a downward direction while minimizing the risk of inversion.



LOW
ANCHOR POINT

BELT



Pressure and balance zone of the harness anchor point: lower abdomen.

Intended for: For experienced users who prioritize efficiency while ascending.

